

Instructions for updating the SRN firmware

Unzip the file 'Printer Utility_Burroughs V1.0.30.0.zip' to a convenient place on your hard disk. For these instructions it is assumed that the files are unzipped to the folder C:\Temp



Printer Utility_Burroughs V1.0.3.0.zip

Instructions for updating the SRN firmware

Instructions for upgrading the firmware

1. Unzip the desired firmware file
 - a. For 'new' firmware, unzip file to a convenient place on your hard disk. For these instructions it is assumed that the files are unzipped to the folder C:\Temp
 - b. For 'old' firmware, unzip file to a convenient place on your hard disk. For these instructions it is assumed that the files are unzipped to the folder C:\Temp
2. Start the program C:\Temp\Printer Utility_Burroughs V1.0.30.0\Utility.exe



Instructions for updating the SRN firmware

3. Click on 'Port Set'. Change the 'Port Type' to 'USB' and then click on 'OK'



The 'Port Set' dialog box is titled 'Port Set' and contains the instruction 'Select printer and Confirm Port settings'. It features a key icon. The settings are organized into several sections:

- Printer Name:** SRN 2PRT
- Port Type:** USB
- COM Setting:**
 - Port Name: COM1
 - Data Bits: 8
 - Baud Rate: 9600
 - Stop Bits: 1
 - Protocol: DTR/DSR
 - Parity: None
- LPT Setting:**
 - Port Name: LPT1
- USB Setting:**
 - Port Name: USB-0
- Net Setting:**
 - Set IP: 0 - 0 - 0 - 0
 - Auto Get IP: (radio button)
- Driver Selecting:**
 - Driver Name: SRN 2PTR(U) 1

At the bottom, there is a checkbox for 'Test Connection' which is checked, and two buttons: 'OK' (with a green checkmark) and 'Cancel' (with a red X).

Instructions for updating the SRN firmware

- Click on 'FW Download'




- Select the '*.JK' radio button, then click on 'Open'




Instructions for updating the SRN firmware

6. To install the firmware, navigate to the C:\Temp\ folder and select the firmware file *.JK



7. Click 'Open', then click 'Download'. A progress meter will be displayed while the firmware is being downloaded. When completed, an update successful dialog box should be displayed.




8. Close the dialog box, cycle power on the printer. Repeat steps 3 thru 5 to re-establish communications with the printer and prepare for downloading a second firmware file then continue on to step #9.

Instructions for updating the SRN firmware

9. Select the '*.EEP' radio button and then click 'Open'



10. Navigate either to the folder C:\Temp\ and select the file *.EEP. This is the same file regardless of whether you're installing 'new' or 'old' firmware.



11. Click on 'Open' and then 'Download'. The same dialog box should be displayed as mentioned in step #7. Upon successful completion, cycle power on the printer. The firmware has now been updated. Proceed with updating the driver

Instructions for updating the SRN firmware

Please contact our Technical Support team for assistance.

TECHNICAL SUPPORT

Phone: 847-446-2285

Email: support@digitalcheck.com